

Originator : KEVIN MILLER Schedule Date :  
Planner : KEVIN MILLER Priority : 3C  
Drawing No : 1CCE-M2014 Clearance : NO  
Equip No/Cat: 1CCE--D 1 Tag Request :  
Project ID : 1CCE-FAN-1D Text ID :  
Shutdown : N No Shutdown Frequency : NOT SCHEDULED  
Ref No : Last Reading : No Reading

Date Completed: \_\_\_\_\_ Failure Code: \_\_\_\_\_  
Completed By : \_\_\_\_\_ Signature : \_\_\_\_\_  
Accepted By : \_\_\_\_\_ Signature : \_\_\_\_\_

## \*\* Delay Codes Legend \*\*

W=Whse C=CrSp T=Tag TL=Tool P=Plan

## \*\* Record Time Daily \*\*

Delays

Step	Job Scope	MN	DY	Safety and Additional Information	Emp No	Date	Hours	Code/Hrs
1	TIME EXPENDED FOR BOB WILSON TO SET UP DI BOTTLE REGEN STATION AND WORK BENCH AS NOTED BELOW.  =====	2	1	***** SAFETY / ENVIRONMENTAL REQUIREMENTS: A. ALWAYS WEAR THE REQUIRED PPE.  B. NO WORK CARD REQUIRED.  ***** ADDITIONAL INFORMATION: A. OBTAIN ALL THE MATERIAL STAGED WHICH IS LISTED ON THE PARTS PAGE. YOU WILL NEED ADDITIONAL MISC MATERIAL FROM THE WAREHOUSE.				
	=====							
	BOB HAS ALREADY WALKED THIS JOB DOWN WITH KEVIN AND NATHAN AND KNOWS WHAT IS NEEDED. =====							
	=====							
	THIS JOB IS TO BE DONE IN BOTH UNITS. =====							
	=====							
	***** JOB SCOPE: 1. INSTALL A STAINLESS STEEL WORK BENCH AND SINK BASIN IN THE HVAC ROOM. PUT WHERE OLD PUMP WAS REMOVED NEAR THE FLOOR DRAIN AND THE DEMIN WATER CAPPED OFF TAP.  2. INSTALL A FILTER CANNISTER & FILTER AND PLUMB INTO CAPPED OFF DEMIN WATER LINE. PLUMB A HOSE TO THE FLOOR DRAIN NEARBY.  3. SET UP THREE BOTTLES WITH BEADS AND SET ON THE "FULL" SIDE. MAKE AN AREA ON THE BENCH FOR FULL AND EMPTY CYLINDERS. COME UP WITH A WAY TO MARK THEM. LET ME KNOW IF YOU WANT ME TO BUY ANYTHING ELSE. YOU MAY ALSO NEED TO MOUNT A BACK PLATE TO THE WORK BENCH TO SUPPORT THE BOTTLES OR PUT THEM UNDERNEATH ON THE SHELF.  4. COORDINATE A TRAINING CLASS WITH							

Job Feedback/Historical Notes:

\*\* IMPORTANT NOTICE \*\*  
YOU ARE RESPONSIBLE FOR YOUR OWN SAFETY AND MUST ENSURE THAT THE REQUIRED PPE IS WORN FOR EVERY JOB YOU ARE DOING. IF YOU HAVE ANY QUESTIONS CONCERNING THE WORK RULES, SAFETY CODES, OR REQUIRED PPE, PLEASE CONTACT YOUR SUPERVISOR.



02-53663-45

IP7013338

CREW: 60

WORK ORDER TYPE: PM REPAIR

02-53663-45

ISSUE DATE 01/06/11

Page 2 Of 3

Step	Job Scope Cont'd	MN	DY	Safety and Additional Information Cont'd	Notes Cont'd:
1	NATHAN AND ALL THE SPARKIES ON HOW WE ARE GOING TO HANDLE THIS PROCESS WHEN A DI TANK GOES INTO ALARM.				

IP7013339

## \*\* Work Order Parts List \*\*

Part No	Description	PO/Req/SIR	Date Due	U/M	Reqd	Commit	Issued/Rcvd
-----	-----	-----	-----	---	-----	-----	-----
1 21972	METER, LAB EQUIPMENT	S 331544	10/22/05	EA	2	0	2
2 46441	RESIN, MIXED BED	S 331544	10/22/05	CF	0	0	0
3 79232	TANK, DEIONIZATION	S 331544	10/22/05	EA	6	0	6
4 79237	HOUSING, FILTER	S 331544	10/22/05	EA	2	0	2
5 79260	CARTRIDGE, FILTER	S 331544	10/22/05	EA	2	0	2
6 DIRECT	WORKBENCH, WITH CENTER SINK, SS, HEAVY-DUTY, OPEN LEG, GLOBA	06-50265	10/22/05	EA	2	0	2
7 DIRECT	COUPLING BODY, BULKHEAD PANEL MOUNT, 1/2" HOSE BARB, SHUTOFF	06-54535	05/20/06	EA	3	0	3

IP7013340